## **Tech Tips**

TT 66-07-96



Date: 2007

## 2004 > Phaeton – Missing Underbody Plugs

It is recommended that dealers receiving any Phaetons from transport check the underbody for missing body plugs. Tow-ins and auction vehicles should also be inspected. The body plugs may have been removed to tie down the vehicle during transport and were not reinstalled. Missing body plugs could lead to water and debris infiltration and possible electrical system concerns. To properly install a new body plug: 1) Clean the surrounding area, 2) Apply anti-corrosion wax (D 322 000 A2) to the area, 3) Install the new plug. See illustration 803-36 for plug information in ETKA.

## © 2009 Volkswagen Group of America, Inc.

Page 1 of 1

All rights reserved. Information contained in this document is based on the latest information available at the time of printing and is subject to the copyright and other intellectual property rights of Volkswagen Group of America, Inc., its affiliated companies and its licensors. All rights are reserved to make changes at any time without notice. No part of this document may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, nor may these materials be modified or reposted to other sites, without the prior expressed written permission of the publisher.